




PROFESSIONAL PHOTO LAMINATOR OWNER'S MANUAL



PLEASE READ AND SAVE INSTRUCTIONS

ROYAL SOVEREIGN INTL.INC.

EDNord - Istedgade 37A - 9000 Aalborg - Telefon 9633 3500

TABLE OF CONTENTS

TOPICS	PAGE
	0
INTRODUCTION	
SAFETY PRECAUTIONS	
CHARACTERISTICS OF NPH-1200N/900N	
SPECIFICATIONS	
SETUP	_
MAJOR PARTS IDENTIFICATION	
CONTROL PANEL INSTRUCTIONS	
1.CONTROL PANEL SETTINGS	
2.LCD WINDOW	
3.BUTTON FUNCTIONS	
4.HOW TO SET THE BUTTONS	10
*SET TEMPERATURE	
*SPEED CONTROLS	10
*CHECK TEMPERATURE ON THE ROLLER	10
*MEMORY WORKING CONDITION AND	
USING THE MEMORY SETTING	11
*COLD MODE	11
LAMINATING STEPS	12
1.HOT LAMINATING	12
2.COLD LAMINATING	13
3.COLOR FOIL LAMINATING	14
4.MOUNT BOARD LAMINATING	15
HOW TO CLEAN ROLLERS AND REMOVE STUCK	
OR JAMMED FILMS	16
IMPORTANT SAFETY CONCERNS	17
MAINTENANCE	17
A/S PARTS	17
TROUBLE SHOOTING	17
ONE YEAR LIMITED COMMERCIAL/PROFESSIONAL WARRANTY	18

INTRODUCTION

Thank you for purchasing a Royal Sovereign Laminating Machine.

To insure high quality lamination, please read this instruction manual thoroughly. For additional product support or factory-direct ordering information, call Royal Sovereign Customer Service at (201)568-0830 or toll free call, (800)397-1025.

SAFETY PRECAUTIONS

The safety recommendations outlined in this section are to be read, understood and followed before operating the machine.

Keep this information for future reference. Failure to comply with any of the following safety procedures could result in serious personal injuries

- To prevent the possibility of electrical shock, do not immerse machine in water or permit liquids to get inside.
- Do not allow articles of clothing (neckties, scarves, etc.) or papers near the front or rear of the machine while operating as they could get cought by the rollers and be pulled inside, causing personal injury.
- 3. Do not attemp to laminate that exceed total recommended material thickness.
- 4. Do not operate machine for any other purpose than its intended use.
- 5. Do not operate machine when electrical plug or power cord is damaged.
- Turn off the power when not in use. Unplug machine before moving it or when it is not in use for an extended period of time.
- 7. This machine is indoor use only.
- 8. Do not alter the electric plug in any use.

CHARACTERISTICS OF LAMINATOR NPH-1200N/900N

This machine has been designed using the latest laminating technology.

- 1. This machine is controlled by a state-of-the-art Microprocessor.
 - a) Protect the rollers—When the power is off or a power failure occurs, rollers continue to turn until the unit properly cools down.
 - b) Automatic overheating protection—If a temperature sensor should fail,
 the heating elements will not heat up.
 - c) You can set your own operating conditions into "Memory".
- Temperature and speed can be adjusted, to properly laminate various film thickness.
- A buzzer rings, alerting you that a butten has been pressed. This prevents accidental setting changes.
- 4. Roller cover may be opened for easy access to clean the rollers.
- 5. Thermostats are used to economically maintain consistent temperature.

SPECIFICATIONS

Description	NPH - 1200N	NPH - 900N
Dimensions(w x d x h)	580x290x135mm (22.8"x11.4"x5.3")	505x290x135mm (19.9"x11.4"x5.3")
Max.Laminating Width	330mm (13")	240mm (9.4")
Max.Lam. Thickness	2mm (1/12")	
Film Thickness	75 ~ 250mic (3 ~ 10 mil)	
Transport Type	Four Roller (no carrier)	
Heat Source	Hot Roller Type	
Pre-Heating Time	4 ~ 5 min	
Temp. Operating Range	20 ~ 160℃	
Cooling Fan Type	DC FAN	
Motor Type	DC GEARED MOTOR	
Max. Laminating Speed	750mm/min (29.5" per min)	
Weight	11Kg (24 lbs)	9Kg (20 lbs)
Voltage / Cycle	AC 120V/60Hz (AC230~240V ,50/60Hz)	
Power Consumption	1000W	850W

SETUP


Place laminator on a sturdy, flat work surface. Allow ample clearence behind laminator for laminated document or photograph to exit completely without bending.

Connect laminator to an electrical outlet that matches laminator's rated voltage and power requirements.

If an extension cord is required, use a cord rated higher than the laminator's capacity.

EDNord - Istedgade 37A - 9000 Aalborg - Telefon 9633 3500

MAJOR PARTS IDENTIFICATION




- 1. Top Cabinet
- 2. Roller Cover
- 3. Roller Cover Screws
- 4. Control Panel
- 5. LCD Window
- 6. Input
- 7. Output
- 8. Power Cord

CONTROL PANEL INSTRUCTIONS

Appropriate speed and temperature may be set, using the LCD controller.

The LCD panel was designed for convenience, by incorporating the ability to program your settings into "Memory".

1. CONTROL PANEL SETTINGS



2. LCD WINDOW



- 1. 0 3 Mil 4 Mil 5 Mil 7 Mil 10 Foil
- * 6 film thickness options
 75 Mic=3 mil, 100 Mic=4 mil, 125 Mic=5 mil
 175 Mic=7 mil, 250 Mic=10 mil
- 2. SPEED
- * 7 speed options

 Setting 1 is slowest / Setting 7 is fastest
- 3. TEMPERATURE

Display the present temperature.



Is displayed when the present temperature is reached.




Indicates to wait till blinking stops.

Current temperature is higher or lower than the

preset temperature.




Displayes the direction of the rollers.





Shows cold function.

3. BUTTON FUNCTIONS



T-Check

: Check current temperature

HOT/COLD

: Hot/Cold function



: Working condition and

Cold function cancel



: Increase temperature



: Decrease temperature



: Increase speed

: Decrease speed



: Restore the memorized

working setting

: Restore the memorized

working setting





: Power On/Off

4. HOW TO SET THE BUTTONS

(Buzzer rings each time you press the button.)





- 1.Temperature available range from 20℃ to 160℃.
- 2.Each time you press or to set temperature, it will change 1°C(1°F) at a time. If you press the button for more than 2 seconds, temperature will change automatically.



4 Mil

1.You

SPEED CONTROLS

- 1. You can use 7 different lamination speed.
- 2.You can change speed with









***CHECK TEMPERATURE ON THE ROLLER ***

- 1. Press (T-Check) button when check the current temperature.
- The current temperature will blink on the display for a second and turns back to the setting mode.




MEMORIZING WORKING CONDITION AND USING THE MEMORIZED WORKING CONDITION





1) Memorizing working condition

- 1. The laminator can memorize up to 6 settings.
- 2. Use up and down arrows to set



This setting is memorized and confirmed when the light blinks.

4. To enter other settings into memory, repeat steps 2 and 3



2) Using the memorized settings

- 1. You can choose any one of 6 settings in memory.
- 2. Use the up and down arrows to select a setting form memory.









COLD MODE

- 1. Press HOT/COLD button. It will show a Son the display.
- 2. The speed will always be shown "2" and there is no memory setting this function.
- 3. Speed can be varied 0 to 7 by selecting \(\textbf{\subset} \) or \(\textbf{\subset} \) button
- You can release the machine from cold mode by pressing HOT/COLD

LAMINATING STEPS

1. HOT LAMINATING

- 1. Press the power button.
- 2. Please refer Information Panel on the front of product.
- 3. Select a memory setting by pressing the




- 4. It is ready when the LCD window shows
- 5. After Insert document or photograph to be laminated into a laminating pouch, insert pouch squarely into opening slot.
- 6. Finished laminated pouch will exit through rear of machine.
- 7. Emerging laminated document is hot to touch. Please handle it to be cooled down.

 (If document is not laminated well, do lamination again.)
- 8. When the machine is on for an extended period of time, use a slightly lower temperature setting as the internal temperature of the machine may actually be higher than the preset temperature, which may cause the document may ripple or bend.
- 9. When you are finished laminating, press the power button to turn off.

USEFUL INFORMATION

* When continuously laminating, the ready signal (waiting signal may be displayed on LCD window.



At this time, if pouch is being laminated, finish laminating and then laminate new one after is showed.

* Do not laminate empty or thin pouch on a thick film setting.

The pouch could stick to the roller.

* Do not unplug laminator while laminating.

This could be fatal for the rollers due to the high internal temperature.

2. COLD LAMINATING

- 1. Press the power button to turn on.
- 2. Press HOT/COLD
- 3. It is ready when LCD window shows and the buzzor rings three times.
- 4. Insert document into a Royal Sovereign cold laminating pouch as follows.

HOW TO ATTACH DOCUMENT ON COLD POUCH FILM



- 1) Prepare cold pouch film.
- 2) Remove protective paper inside cold pouch. (Be careful not to allow the pouch to close and seal itself closed. If the pouch closes on itself and seals, you will not be able to the document to be laminated inside.)
- Place document squarely into the pouch, where the protecting paper was.
 Cold film's minimum border of about 3mm(1/8") is necessary to provide a proper edge seal.
- 4) Beware of dust while inserting document.
- 5) Feed pouch squarely into opening slot.
- 5. Finished laminated pouch will exit through rear of machine.
- 6. When you are finished laminating, press the power button to turn off.

USEFUL INFORMATION

If it has recently been used for hot lamination, allow the rollers to be cooled down about 20~30 minutes.

3. COLOR FOIL LAMINATING

Your laminator has ability to add color by applying color foil to documents copied or printed by lasor printer or toner copier.

PAPER CARRIER is required

- 1. Press the power button to turn the laminator on.
- 2. Find FOIL FUNCTION using the up arrow.
- 3. It is ready when LCD window shows
- and the buzzer rings 3 times.
- 4. Position the color foil on document and put it in paper carrier.
- 5. Feed paper carrier squarely into opening slot.
- 6. Finished laminated paper will exit through rear of machine.
- 7. When you are finished laminating, press the power button to turn off.

USEFUL INFORMATION

- * The document, which has been foil laminated, is pretty hot and easily bent. Try not to touch the document until it has cooled down.
- * When you are applying foil to small areas or using several colors, use tape provided. to hold the foil in place.

(Foil laminating temperature is set for a bond paper.)

4. MOUNT BOARD LAMINATING


- **You can laminate photographs or pictures on a hard mounting board up to 2mm thickness**
- 1. Press the power button to turn on.
- 2. Temperature 130 and speed 1 is set for Foil function.
- 3. It is ready when LCD window shows (and the buzzor rings 3 times.
- 4. Set material on Mount board then slide them into the opening slot
- 5. Finished board will exit through the rear slot of machine.
- 6. When finish, press the power button and turn off.

USEFUL INFORMATION

- * The document, which has been mounting board laminated, is pretty hot and easily bent. Try not to touch the document until it has cooled down.
- * When laminating to mounting board 2mm, pressure adjustment is needed for good quality lamination.

LAMINATION PRESSURE ADJUSTMENT

- 1. Unscrew 6 retaining screws of bottom and lift off top cover.
- Locate each end of left and right pressure spring and set in the upper position, as shown.




3. Reassemble top cover with retaining screws and do lamination.

*For general lamination, set pressure springs to lower position.

HOW TO CLEAN ROLLERS AND REMOVE STUCK OR JAMMED TO FILMS

1. Cleaning rollers with a clean and thick paper

1) If film adhesive apears on the laminated pouch surface, Insert a sheet of clean, thick paper (about 0.5mm(1/50") thickness) into the machine 2~3 times on 100°C(212°F) setting. The paper will attract the excess adhesive from the roller.



2. Cleaning rollers with cleaning solvent.

- 1) When rollers are hot, turn on and set "COLD" mode to cool them down.
- 2) After cooling, the machine automatically stops.
- Unscrew 2 retaining screws on the cover by using a screw driver or a coin. Turn them towards counterclockwise. After remove them, lift off the cover.
- 4) Use a recommended silicon roller cleaning solvent such as Laminex Poly-Off or equivalent, on a lint-free cloth to clean residue of laminate adhesive on exposed roller surface.
 - You can clean every corner of the rollers as turn the power switch and make them roll Prevent any liquid from spilling into the unit.
- 5) Re-assemble the unit in reverse-order of disassembling.
- * Do not turn the unit on until the rollers are completely dry. Wet rollers could cause serious harm.

IMPORTANT SAFETY CONCERNS

- 1. Please be cautious that neckties, necklaces, long hair and clothing are kept well away while operating the laminator.
- 2. Prevent children from accessing the machine.
- 3. Make certain that the machine is connected to an adequate power source.
- 4. Do not use for any purpose other than lamination.

MAINTENANCE

- 1. Width of upper and lower side of film should be same in order not to allow melted adhesive resin to stick to the rollers.
- 2. Routine cleaning of rollers is required to prevent adhesive build-up
- 3. Always keep the area around the machine clean. To remove dust, finger prints, etc. from housing, use dilutedalcohol on lint-free cloth and do not permit liquids to get into laminator. (Do not use strong alcohol or petroleum-based cleaning solvents or abrasives.)

ASSEMBLY PARTS

1. Owner's manual : 1

2. Roller cleaning papeer: (A3) 3 pcs

TROUBLE SHOOTING

Symptom	Cause	Check point
* Motor doesn't work.	. Power cord may not be plugged in.	. Check the power cord.
	. Power switch is OFF	. Check that the switch is on.
* Film is not laminated.	. Cold mode may be set.	. Change the function to hot lamination
* Result of lamination is not clear.	. Temperature on the roller is too low or laminating is too fast.	. Increase temperature or decrease speed.

ONE YEAR LIMITED COMMERCIAL/PROFESSIONAL WARRANTY

This product is warranted for 1 year from date of purchase to be free from electrical or mechanical defects in material and workmanship. Should product fail to operate during warranty period, return it, freight prepaid, to Royal Sovereign Corporation, 100 West Sheffield Avenue, Englewood, NJ 07631, for service. There will be no charge for parts and labor to repair or replace this product whthin warranty period. When returning machine, purchaser must include a photo copy of purchase receipt and a check ormoney order for \$20.00 to cover return shipping and handling. Please include a briefnote explaining the problem.

This warranty is voided in cases of improper use, abuse, mishandling and unauthorized modifications or repairs. This warranty does not cover suitability of this product for specific applications. Determining suitability of each application is solely the reponsibility of the user. This warranty does not cover incidental or consequential damages resulting from its use.

This warranty is not to be considered a service contract, and does not cover routine adjustment, cleaning, jams or removal of materials that have become stuck inside machine.

This warranty does not cover damage or injury resulting from improper use or failure to follow the instruction manual provided. In no event will manufacturer, importer, warranty service center, its agents or assigns, be liable for losses, either direct or indirect, including but not limited to special, incidental, consequential, or punitive damages whatsoever incurred arising out of any breach of warranty by manufacturer, importer, warranty service center, their heirs or assigns or successors in interest. Purchaser hereby accepts and agrees to these conditions by returning the registration card to the warranty service center. There are no other warranties either expressed or implied other than this written limited warranty. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Warranty registration card must be mailed within ten days of purchase.

WARNING: Please read all safety warnings and instructions before using this product. Improper use or failure to read and follow instructions may cause a fire, the unit to overheat, or serious personal injury.

EDNord - Istedgade 37A - 9000 Aalborg - Telefon 9633 3500